

Adhesive Backed Wall Fabric (Wall Graphics) - Clear Ultra Removable Adhesive, 90# Liner

For Solvent & UV Curable Printers

Instructions

Pick a smooth, dry and clean surface- The most traditional places include any wall, door, window or car. When placing the Wall Fabric on a standard painted wall, make sure the wall has been previously primed prior to painting (otherwise the paint may come off) If you place your Wall Fabric on a pebbly, textured surface that has used egg-shell paint or a very porous surface (i.e. brick, cement walls, Stucco) you may receive poor results. When painting your walls make sure you allow 21 days for out gassing to prevent bubbling.

We also suggest avoiding placement above fire-places. Outdoors use different kinds of inks, especially any solvent or latex inks so we recommend using a liquid lamination or clear coat for longevity.

Cleaning

Use a warm, damp cloth or sponge to clean the wall surface or window and allow it to completely dry. In some cases you can add alcohol to water for better adhesion. Make sure all previous cleaning solutions are completely gone. Outdoors we suggest you use a pump spray to save time. You can remove and replace the Wall Fabric multiple times; however, once the adhesive collects too much dust, dirt and fibers it will become less effective and Wall Fabric may not stick as well to the surface. Also when cleaning Wall Fabric because it is a fabric, you cannot clean the material unless you coat the ink with a liquid or spray laminate.



Perfect for:

- Interior and exterior applications
- Windows
- Doors
- Sign Boards
- Other Flat Surfaces

Sticks to any non-porous flat surface. Removable, reusable, repositionable and removes with no residue. Print to edge - no border needed around printed graphics.

Peel & Stick

Depending on the size of your Wall Fabric, it may be helpful to have two people install it. Try not to let the adhesive come together, or let the Wall Fabric fold up against itself. It's okay if it does, you can separate it by carefully pulling it apart and you may want two people to do this on larger images. Start at the top of your Wall Fabric Image and pull down approximately 4-6" of the backer and crease the back of the backer. Simply apply the 4-6" of exposed adhesive area to your chosen location. It can be repositioned many times. Once your square then continue to slowly pull the backer downward in 4-6" increments, smoothing the Wall Fabric as you go.

Depending on the size, it may be helpful if one person pulls down the backer, while the other smooth's the surface. You can use a plastic dry wall knife (like 6-8") to smooth out. If there are any bubbles or wrinkles, you can lightly press or smooth them out, or just peel back that area and re-apply. **Please note:** Pressing too hard will not damage the Wall Fabric; however, it may cause your hands to gather ink (due to the natural oils on your hands), and could transfer from your hands onto another surface.

Outdoors

You can place your Wall Fabric on any outdoor, flat surface; however, it may fade after several months of strong sun exposure due to the longevity of the water base/pigmented inks. Solvent/UV Inks tend to last a little longer. When using UV Curable printers, it is possible to overheat the material and cause the adhesive to weaken up to 50% during printing process. Although this occurrence is infrequent, it is important to keep the lamps at a lower setting when using UV cure printers.

Suggestions

If a bubble re-appears over the next day or two, pressing and lightly rubbing can remove it. This can happen occasionally if oil, dirt, or dust is on your surface. You may also use a pin to pop the bubble, and then smooth it out with your fingers in a circular motion. In the very rare instance that it keeps re-appearing, you may want to move your Wall Fabric to another area as there is something wrong with the surface.

Disclaimer

The conditions and method of handling, storage, use and disposal of the products listed above are beyond our control. For this and other reasons, we do not assume responsibility and expressly disclaim liability for loss, damage or the expense arising out of or in any way connected with the handling, storage, use or disposal of these products. There are no understandings or representations of any kind whatsoever except as expressly set forth herein.